

Media Settings

Media Settings: To be used in combination with the ICC profile when printing. The reference guide for each paper and which media setting to use is below.

Epson Printer ▾

Epson Artisan 1430 Model ▾

Moab Paper	Media Type Setting When Printing
Artist Card	Enhanced Matte or Archival Matte or Ultra Premium Presentation Matte
Colorado Fiber Gloss 245	Ultra Premium Photo Paper Pro Gloss
Colorado Fiber Satine 245	Ultra Premium Photo Paper Pro Gloss
Entrada Rag Bright 190/300/290	Enhanced Matte or Archival Matte or Ultra Premium Presentation Matte
Entrada Rag Natural 190/300/290	Enhanced Matte or Archival Matte or Ultra Premium Presentation Matte
Entrada Rag Natural Coldpress 300	Enhanced Matte or Archival Matte or Ultra Premium Presentation Matte
Entrada Rag Textured 300	Ultra Premium Presentation Matte
Juniper Baryta Rag 305	Ultra Premium Photo Paper Pro Gloss
Lasal Dual Semigloss 330	Ultra Premium Photo Paper Pro Gloss
Lasal Exhibition Luster 300	Premium Photo Paper Glossy
Lasal Photo Gloss 270	Ultra Premium Photo Paper Pro Gloss
Lasal Photo Matte 230/235	Enhanced Matte or Archival Matte or Ultra Premium Presentation Matte
Moenkopi Unryu 55	Enhanced Matte or Archival Matte or Ultra Premium Presentation Matte
Slickrock Metallic Pearl 260	Ultra Premium Photo Paper Pro Gloss
Slickrock Metallic Silver 300	Premium Glossy Photo Paper
Somerset Museum Rag 300	Enhanced Matte or Archival Matte or Ultra Premium Presentation Matte
Somerset Enhanced Velvet 225/255/505	Enhanced Matte or Archival Matte or Ultra Premium Presentation Matte

Downloading and Installing a profile

For instructions on installing ICC profiles please visit:
www.moabpaper.com/profile-use-and-installation

Watch our recorded webinars on YouTube:
www.youtube.com/moabpaper



Ultimate Guide to Fine Art Printing

by Lester Picker

Free Download | FineArtPrinteBook.com



Questions? Email us info@legionpaper.com