

Media Settings

Media Settings: To be used in combination with the ICC profile when printing. The reference guide for each paper and which media setting to use is below.

Epson Printer ▼

Epson Stylus Pro 4880 Model ▼

Moab Paper	Media Type Setting When Printing
Colorado Fiber Gloss 245	Premium Glossy Photo Paper
Colorado Fiber Satine 245	Premium Luster or Ultra Premium Photo Paper Luster
Entrada Rag Bright 190/300/290	Watercolor Radiant White
Entrada Rag Natural 190/300/290	Watercolor Radiant White
Entrada Rag Textured 300	Watercolor Radiant White
Juniper Baryta Rag 305	Premium Luster or Ultra Premium Photo Paper Luster
Lasal Dual Semigloss 330	Premium Luster or Ultra Premium Photo Paper Luster
Lasal Exhibition Luster 300	Premium Luster or Ultra Premium Photo Paper Luster
Lasal Photo Gloss 270	Premium Glossy Photo Paper
Lasal Photo Matte 230/235	Enhanced Matte or Archival Matte or Ultra Premium Presentation Matte
Moenkopi Kozo 110	Enhanced Matte or Archival Matte or Ultra Premium Presentation Matte
Moenkopi Unryu 55	Enhanced Matte or Archival Matte or Ultra Premium Presentation Matte
Slickrock Metallic Pearl 260	Premium Photo Paper Semi Gloss
Slickrock Metallic Silver 300	Premium Photo Paper Glossy
Somerset Museum Rag 300	Velvet Fine Art
Somerset Enhanced Velvet 225/255/505	Textured Fine Art

Downloading and Installing a profile

For instructions on installing ICC profiles please visit:
www.moabpaper.com/profile-use-and-installation

Watch our recorded webinars on YouTube:
www.youtube.com/moabpaper



Ultimate Guide to Fine Art Printing

by Lester Picker

Free Download | FineArtPrinteBook.com



Questions? Email us info@legionpaper.com