

Media Settings

Media Settings: To be used in combination with the ICC profile when printing. The reference guide for each paper and which media setting to use is below.

Canon Pixma PRO-100

Model

Canon

Printer

Moab Paper	Media Type Setting When Printing
All Profiles Updated February 2021	
Artist Card	Matte Photo Paper
Anasazi Canvas Matte 350	Matte Photo Paper
Colorado Fiber Gloss 245	Other Glossy Paper
Colorado Fiber Satine 245	Other Glossy Paper
Entrada Rag Bright 190/300/290	Matte Photo Paper
Entrada Rag Natural 190/300/290	Matte Photo Paper
Entrada Rag Natural Coldpress 300	Matte Photo Paper
Entrada Rag Textured 300	Matte Photo Paper
Juniper Baryta Rag 305	Photo Paper Pro Platinum
Lasal Dual Semigloss 330	Photo Paper Pro Platinum
Lasal Exhibition Luster 300	Photo Paper Pro Platinum
Lasal Photo Gloss 270	Other Glossy Paper
Lasal Photo Matte 230/235	Matte Photo Paper
Moenkopi Kozo 110	Matte Photo Paper
Moenkopi Unryu 55	Matte Photo Paper
Slickrock Metallic Pearl 260	Photo Paper Pro Platinum
Slickrock Metallic Silver 300	Photo Paper Pro Platinum
Somerset Museum Rag 300	Matte Photo Paper
Somerset Enhanced Velvet 225/255/505	Matte Photo Paper

Downloading and Installing a profile

For instructions on installing ICC profiles please visit:
www.moabpaper.com/profile-use-and-installation

Watch our recorded webinars on YouTube:
www.youtube.com/moabpaper



Ultimate Guide to Fine Art Printing
 by Lester Picker

Free Download | FineArtPrinteBook.com



Questions? Email us info@legionpaper.com