

Media Settings

Media Settings: To be used in combination with the ICC profile when printing. The reference guide for each paper and which media setting to use is below.

Epson

Printer ▼

Epson SureColor P7000 / P9000 Model

Moab Paper	Media Type Setting When Printing
Anasazi Canvas Matte 350	Canvas Matte
Colorado Fiber Gloss 245	Premium Luster or Ultra Premium Photo Paper Luster
Colorado Fiber Satine 245	Premium Luster or Ultra Premium Photo Paper Luster
Entrada Rag Bright 190/300/290	Ultrasmooth Fine Art
Entrada Rag Natural 190/300/290	Ultrasmooth Fine Art
Entrada Rag Textured 300	Ultrasmooth Fine Art
Juniper Baryta Rag 305	Premium Luster or Ultra Premium Photo Paper Luster
Lasal Exhibition Luster 300	Premium Luster or Ultra Premium Photo Paper Luster
Lasal Photo Gloss 270	Premium Photo Paper Glossy
Lasal Photo Matte 230/235	Ultrasmooth Fine Art
Lasal Dual Semigloss 330	Premium Semigloss
Moenkopi Bizan 300	Velvet Fine Art
Moenkopi Kozo 110	Ultrasmooth Fine Art
Moenkopi Unryu 55	Ultrasmooth Fine Art
Slickrock Metallic Pearl 260	Premium Semigloss
Slickrock Metallic Silver 300	Premium Photo Paper Glossy
Somerset Enhanced Velvet	Velvet Fine Art
Somerset Museum Rag 300	Ultrasmooth Fine Art

Downloading and Installing a profile

For instructions on installing ICC profiles please visit:
www.moabpaper.com/profile-use-and-installation

Watch our recorded webinars on YouTube:
www.youtube.com/moabpaper



Ultimate Guide to Fine Art Printing

by Lester Picker

Free Download | FineArtPrinteBook.com



Questions? Email us info@legionpaper.com