

Media Settings

Media Settings: To be used in combination with the ICC profile when printing. The reference guide for each paper and which media setting to use is below.

Epson Printer ▼

Epson Stylus Photo 1400 Model ▼

Moab Paper	Media Type Setting When Printing
Artist Card	Ultra Premium Presentation Matte
Anasazi Canvas Matte 350	Enhanced Matte or Archival Matte or Ultra Premium Presentation Matte
Colorado Fiber Gloss 245	Premium Luster or Ultra Premium Photo Paper Luster
Colorado Fiber Satine 245	Premium Luster or Ultra Premium Photo Paper Luster
Entrada Rag Bright 190/300/290	Enhanced Matte or Archival Matte or Ultra Premium Presentation Matte
Entrada Rag Natural 190/300/290	Enhanced Matte or Archival Matte or Ultra Premium Presentation Matte
Entrada Rag Textured 300	Enhanced Matte or Archival Matte or Ultra Premium Presentation Matte
Lasal Luster 270	Premium Luster or Ultra Premium Photo Paper Luster
Lasal Photo Gloss 270	Premium Glossy Photo
Lasal Photo Matte 230/235	Enhanced Matte or Archival Matte or Ultra Premium Presentation Matte
Slickrock Metallic Pearl 260	Premium Glossy Photo
Slickrock Metallic Silver 300	Premium Glossy Photo
Somerset Enhanced Velvet 225/255/505	Enhanced Matte or Archival Matte or Ultra Premium Presentation Matte

Downloading and Installing a profile

For instructions on installing ICC profiles please visit:
www.moabpaper.com/profile-use-and-installation

Watch our recorded webinars on YouTube:
www.youtube.com/moabpaper



Ultimate Guide to Fine Art Printing
 by Lester Picker

Free Download | FineArtPrinteBook.com



Questions? Email us info@legionpaper.com