

Media Settings

Media Settings: To be used in combination with the ICC profile when printing. The reference guide for each paper and which media setting to use is below.

Epson

Printer ▾

Epson SureColor P700

Model ▾

Moab Paper	Media Type Setting When Printing
Artist Card	Ultra Premium Presentation Paper Matte
Anasazi Canvas Matte 350	Exhibition Canvas Matte
Entrada Rag Bright 190/300	Ultra Premium Presentation Paper Matte
Entrada Rag Natural 190/300	Ultra Premium Presentation Paper Matte
Entrada Rag Natural Coldpress 300	Velvet Fine Art
Entrada Rag Textured 300	Velvet Fine Art
Juniper Baryta Rag 305	Ultra Premium Photo Paper Luster
Lasal Exhibition Luster 300	Ultra Premium Photo Paper Luster
Lasal Photo Matte 235	Ultra Premium Presentation Paper Matte
Moenkopi Kozo 110	Washi
Moenkopi Unryu 55	Washi
Slickrock Metallic Pearl 260	Ultra Premium Photo Paper Luster
Slickrock Metallic Silver 300	Ultra Premium Photo Paper Luster
Somerset Enhanced Velvet 225/255/505	Velvet Fine Art
Somerset Museum Rag 300	Velvet Fine Art

Downloading and Installing a profile

For instructions on installing ICC profiles please visit:
www.moabpaper.com/profile-use-and-installation

Watch our recorded webinars on YouTube:
www.youtube.com/moabpaper



Ultimate Guide to Fine Art Printing

by Lester Picker

Free Download | FineArtPrinteBook.com



Questions? Email us info@legionpaper.com