

## Media Settings

Media Settings: To be used in combination with the ICC profile when printing. The reference guide for each paper and which media setting to use is below.

Epson Printer ▾

Epson Stylus Pro 7800 / 9800 Model ▾

Moab Paper	Media Type Setting When Printing
Anasazi Canvas Matte 350	Enhanced Matte or Archival Matte or Ultra Premium Presentation Matte
Colorado Fiber Gloss 245	Premium Luster or Ultra Premium Photo Paper Luster
Colorado Fiber Satine 245	Premium Luster or Ultra Premium Photo Paper Luster
Entrada Rag Bright 190/300/290	Watercolor Radiant White
Entrada Rag Natural 190/300/290	Watercolor Radiant White
Entrada Rag Textured 300	Watercolor Radiant White
Juniper Baryta Rag 305	Exhibition Fiber
Lasal Exhibition Luster 300	Ultra Premium Photo Paper Luster
Lasal Photo Gloss 270	Premium Glossy Photo Paper
Lasal Photo Matte 230/235	Enhanced Matte or Archival Matte or Ultra Premium Presentation Matte
Moenkopi Kozo 110	Enhanced Matte or Archival Matte or Ultra Premium Presentation Matte
Slickrock Metallic Pearl 260	Premium Luster or Ultra Premium Photo Paper Luster
Slickrock Metallic Silver 300	Premium Luster or Ultra Premium Photo Paper Luster
Somerset Museum Rag 300	Fine Art Paper
Somerset Enhanced Velvet 225/255/505	Velvet Fine Art

## Downloading and Installing a profile

For instructions on installing ICC profiles please visit:  
[www.moabpaper.com/profile-use-and-installation](http://www.moabpaper.com/profile-use-and-installation)

Watch our recorded webinars on YouTube:  
[www.youtube.com/moabpaper](http://www.youtube.com/moabpaper)



Ultimate Guide to Fine Art Printing

by Lester Picker

Free Download | [FineArtPrinteBook.com](http://FineArtPrinteBook.com)



Questions? Email us [info@legionpaper.com](mailto:info@legionpaper.com)