

Media Settings

Media Settings: To be used in combination with the ICC profile when printing. The reference guide for each paper and which media setting to use is below.

Canon Pixma PRO-9500 II

Model▼

Canon

Printer ▼

Moab Paper	Media Type Setting When Printing
Artist Card	Matte Photo Paper
Anasazi Canvas Matte 350	Canvas
Colorado Fiber Gloss 245	Premium Photo Paper Semi Gloss
Colorado Fiber Satine 245	Premium Photo Paper Semi Gloss
Entrada Rag Bright 190/300/290	Fine Art Photo Rag
Entrada Rag Natural 190/300/290	Matte Photo Paper
Entrada Rag Textured 300	Matte Photo Paper
Juniper Baryta Rag 305	Premium Photo Paper Semi Gloss
Lasal Dual Semigloss 330	Premium Photo Paper Plus Semi Gloss
Lasal Exhibition Luster 300	Premium Photo Paper Semi Gloss
Lasal Photo Gloss 270	Premium Photo Paper Gloss 2
Lasal Photo Matte 230/235	Matte Photo Paper
Monekopi Bizan 300	Inkjet Hagaki
Moenkopi Kozo 110	Inkjet Hagaki
Moenkopi Unryu 55	Inkjet Hagaki
Slickrock Metallic Pearl 260	Premium Photo Paper Platinum
Slickrock Metallic Silver 300	Premium Photo Paper Platinum
Somerset Museum Rag 300	Matte Photo Paper
Somerset Enhanced Velvet 225/255/505	Matte Photo Paper

Downloading and Installing a profile

For instructions on installing ICC profiles please visit:
www.moabpaper.com/profile-use-and-installation

Watch our recorded webinars on YouTube:
www.youtube.com/moabpaper



Ultimate Guide to Fine Art Printing

by Lester Picker

Free Download | FineArtPrinteBook.com



Questions? Email us info@legionpaper.com