



www.moabpaper.com

## Media Settings

Media Settings: To be used in combination with the ICC profile when printing. The reference guide for each paper and which media setting to use is below.

Model

Canon

Printer

Canon Pixma PRO-9000

Moab Paper	Media Type Setting When Printing
Colorado Fiber Gloss 245	Photo Paper Plus Semi-Gloss
Colorado Fiber Satine 245	Photo Paper Plus Semi-Gloss
Entrada Rag Bright 190/300/290	Fine Art Photo Rag
Entrada Rag Natural 190/300/290	Fine Art Photo Rag
Entrada Rag Textured 300	Fine Art Photo Rag
Juniper Baryta Rag 305	Photo Paper Plus Semi Gloss
Lasal Exhibition Luster 300	Photo Paper Plus Semi Gloss
Lasal Photo Gloss 270	Photo Paper Plus Glossy
Lasal Photo Matte 230/235	Fine Art Photo Rag
Moenkopi Kozo 110	Inkjet Hagaki
Moenkopi Unryu 55	Matte Photo Paper
Slickrock Metallic Pearl 260	Glossy II
Slickrock Metallic Silver 300	Premium Photo Paper Gloss 2
Somerset Enhanced Velvet 225/255/505	Fine Art Photo Rag

## Downloading and Installing a profile

For instructions on installing ICC profiles please visit:  
[www.moabpaper.com/profile-use-and-installation](http://www.moabpaper.com/profile-use-and-installation)

Watch our recorded webinars on YouTube:  
[www.youtube.com/moabpaper](http://www.youtube.com/moabpaper)



Ultimate Guide to Fine Art Printing  
by Lester Picker

Free Download | [FineArtPrinteBook.com](http://FineArtPrinteBook.com)



Questions? Email us [info@legionpaper.com](mailto:info@legionpaper.com)