



www.moabpaper.com

Media Settings

Media Settings: To be used in combination with the ICC profile when printing. The reference guide for each paper and which media setting to use is below.

Epson Printer

Epson XP-15000 Model

Moab Paper	Media Type Setting When Printing
Artist Card	Premium Presentation Paper Matte
Anasazi Canvas Matte 350	Not Recommended
Entrada Rag Bright 190/300/290/Entradalopes	Premium Presentation Paper Matte
Entrada Rag Natural 190/300/290/Entradalopes	Premium Presentation Paper Matte
Entrada Rag Natural Coldpress 300	Premium Presentation Paper Matte
Entrada Rag Textured 300	Presentation Paper Matte
Juniper Baryta Rag 305	Ultra Premium Photo Paper Luster
Lasal Dual Semigloss 330	Ultra Premium Photo Paper Luster
Lasal Exhibition Luster 300	Ultra Premium Photo Paper Luster
Lasal Photo Matte 235	Premium Presentation Paper Matte
Moenkopi Kozo 110	Presentation Paper Matte
Moenkopi Unryu 55	Presentation Paper Matte
Slickrock Metallic Pearl 260	Ultra Premium Photo Paper Glossy
Slickrock Metallic Silver 300	Ultra Premium Photo Paper Glossy
Somerset Enhanced Velvet 225/255/505	Presentation Paper Matte
Somerset Museum Rag 300	Premium Presentation Paper Matte

Downloading and Installing a profile

For instructions on installing ICC profiles please visit:
www.moabpaper.com/profile-use-and-installation

Watch our recorded webinars on YouTube:
www.youtube.com/moabpaper



Ultimate Guide to Fine Art Printing
by Lester Picker

Free Download | FineArtPrinteBook.com



Questions? Email us info@legionpaper.com