

Media Settings

Media Settings: To be used in combination with the ICC profile when printing. The reference guide for each paper and which media setting to use is below.

Epson Printer ▾

Epson Stylus Pro 11880 Model ▾

Moab Paper	Media Type Setting When Printing
Anasazi Canvas Matte 350	Enhanced Matte or Archival Matte or Ultra Premium Presentation Matte
Colorado Fiber Gloss 245	Semi Gloss
Colorado Fiber Satine 245	Premium Luster or Ultra Premium Photo Paper Luster
Entrada Rag Bright 190/300/290	Ultrasmooth Fine Art
Entrada Rag Natural 190/300/290	Ultrasmooth Fine Art
Entrada Rag Textured 300	Ultrasmooth Fine Art
Juniper Baryta Rag 305	Exhibition Fiber
Lasal Exhibition Luster 300	Premium Luster 260
Lasal Photo Gloss 270	Premium Glossy Photo Paper 250
Lasal Photo Matte 230/235	Enhanced Matte or Archival Matte or Ultra Premium Presentation Matte
Slickrock Metallic Pearl 260	Premium Semigloss Photo Paper 250
Slickrock Metallic Silver 300	Premium Glossy Photo Paper 250
Somerset Museum Rag 300	Ultrasmooth Fine Art
Somerset Enhanced Velvet 225/255/505	Watercolor Radiant White

Downloading and Installing a profile

For instructions on installing ICC profiles please visit:
www.moabpaper.com/profile-use-and-installation

Watch our recorded webinars on YouTube:
www.youtube.com/moabpaper



Ultimate Guide to Fine Art Printing

by Lester Picker

Free Download | FineArtPrinteBook.com



Questions? Email us info@legionpaper.com